

GS-CL5500-v2.0516



CODELOCKS UK HEADQUARTERS

Tel: +44 (0) 1635 239645
Fax: +44 (0) 1635 239644
sales@codelocks.com
www.codelocks.com

Helpline, service & spares
Freephone: 0800 393 405

CODELOCKS INC US

Tel: +1 714 979 2900
Fax: +1 714 979 2902
sales@codelocks.us
www.codelocks.us

Helpline, service & spares
Toll free: 1.877.codelock

CODELOCKS (Australia) PTY LTD

Tel: +61 2 9882 1009
Fax: +61 2 9882 6030
sales@codelocks.com.au
www.codelocks.com.au

Helpline, service & spares
Toll free: 1800 052 131

www.codelocks.com



BASIC PROGRAMS

01 Change the Master Code

Note: The Master Code is 8 digits in length

#Master Code • 01 • New Master Code •

New Master Code ••

Example: #12345678 • 01 • 87654321 • 87654321 ••

Result: The Master Code has been changed to 87654321

02 Change the Sub-Master Code

Note: The Sub-Master Code is 8 digits in length

#Master Code • 02 • New Sub-Master Code •

New Sub-Master Code ••

Example: #12345678 • 02 • 44556677 • 44556677 ••

Result: The Sub-Master Code has been changed to 44556677

03 Delete the Sub-Master Code

#Master Code • 03 ••

Example: #12345678 • 03 ••

Result: The Sub-Master Code has been deleted

15.1 Lock-Down

Prevents the lock from being unlocked by any method except via Master Code or Sub-Master Code:

#Master Code • 15 • 1 ••

Example: #12345678 • 15 • 1 ••

Result: Lock-Down is enabled. Only the Master and Sub-Master Codes can be used to open the lock.

15.2 Cancel Lock-Down

#Master Code • 15 • 2 ••

Example: #12345678 • 15 • 2 ••

Result: Lock-Down is cancelled.

TROUBLESHOOTING

Incorrect Code/Card

If 3 incorrect access attempts are made, the lock will suspend activity for 30 seconds.

Programming Error

If a programming mistake is made, the keypad will flash red and the lock will revert to normal operation.

CLIENTS (USERS)

20.1 Add a Code Client

#Master Code • 20 • 1 • Code ••

Example: #12345678 • 20 • 1 • 3366 ••

Result: The Code 3366 can now be used to unlock the lock.

20.2 Add a One-Time Code Client

#Master Code • 20 • 2 • Code ••

Example: #12345678 • 20 • 2 • 7788 ••

Result: The Code 7788 can be used to unlock the lock once only.

20.3 Add a Smart Card Client

Note: After entering the program below, the lock will wait for a MIFARE based smart card to be placed over the keypad.

#Master Code • 20 • 3 •• present MIFARE card

Example: #12345678 • 20 • 3 •• present MIFARE card

Result: The smart card will be able to unlock the lock.

Note: Up to 150 cards can be registered.

21 Suspend a Code Client

#Master Code • 21 • Code ••

Example: #12345678 • 21 • 1199 ••


Result: The Code 1199 has been suspended.

22 Restore a Code Client

#Master Code • 22 • Code ••

Example: #12345678 • 22 • 1199 ••

Result: The Code 1199 has been restored.



Getting Started

CL5500



ABOUT CL5500

This range of locks can be operated and managed directly via the keypad or via a compatible smartphone by downloading the K3 Connect App. This Getting Started guide contains the common functions to enable you to quickly program your lock.

For detailed instructions, refer to the Programming & Operating Instructions at www.codelockssupport.com

THE BASICS

Master Code

The factory set Master Code is #12345678. This should be changed immediately after installation (Program 01). The Master Code (and Sub-Master Code if set) always start with the # button. This puts the lock in Programming Mode.

Access Methods

The lock supports a maximum of 350 Clients (users): User Codes (100), User Cards (150) and User Compatible Phones (100).

Keypad

The lock has a 12 button, back-lit keypad which includes ★ and # buttons. The # button is only used for programming. The ★ button is used in some programs and with NetCodes.

Code Free

Code Free can be configured via Program 04 (refer to the Programming & Operating Instructions) or via Key-in-Lever by changing the cylinder tailpiece (refer to Installation Instructions).

Remote Release

The lock has two sets of terminals within the front housing for remote release, labelled REM1 and REM2. REM1 is intended for push-button release where the lock will open for the normal set time. REM2 is intended for use where the lock needs to be released for a longer period. When a switch or relay connected to REM2 is closed, the lock will open for a period of 30 minutes after which the lock will revert to normal operation. Refer to Installation Instructions for further information.

THE APP

Manage with the K3 Connect App

The lock can be managed with the K3 Connect App by any Bluetooth compatible smartphone.




The App is available on:

Apple App Store for Apple devices or Google Play™ for Android™ devices by searching for K3 Connect.

- 1 Install the K3 Connect App on your device.
- 2 Once installed, open K3 Connect and select **Create Account**.
- 3 The account creation process includes email confirmation. Once the account has been created, sign-in to the App.
- 4 To add a new lock, touch the + icon on the **Locks** screen.
- 5 Enter the lock DIN and enter a name for your lock (we recommend that you choose a meaningful name). For this lock range the DIN is: CL5510.

Note: The lock DIN is case-sensitive. The same DIN (CL5510) to be used for all CL5500 variants i.e. CL5510, CL5520, CL5500PK etc.

- 6 In the App, touch  and then immediately, on the lock, enter the following program:
#Master Code • 00 • 1 • •
Example: #12345678 • 00 • 1 • •

Note: If you have changed your Master Code, substitute the code used in the example with your own code.

- 7 The lock will now pair with your phone.

For detailed instructions, refer to the Programming & Operating Instructions at www.codelockssupport.com

FACTORY RESET

The lock can be reset to its original factory settings. You may need to do this if the Master Code is no longer known or you no longer have management access via a smartphone. To reset the lock, you must have access to the battery compartment in the rear of the lock.

- 1 Remove a battery.
- 2 Press and hold the **0** button.
- 3 Replace the battery whilst continuing to hold the **0** button.
- 4 After the double beep, release the **0** button.
- 5 Press the **0** button three times.
- 6 If successful, the Blue LED's will burn for 7 seconds.

REGULATORY COMPLIANCE

The device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.